

## Suede Backed Non Woven Wallpaper Hanging Instructions

Whilst we make every effort to ensure that all our wallpapers and borders are of the highest quality, slight variations in shade or pattern may occur during manufacture. Before cutting and hanging wallpapers or borders, please inspect every roll to ensure that they all have the same batch number, are in good condition, and that the edges match correctly. The company cannot accept any liability for defects in the condition of the product or matching that are apparent at the time of hanging, nor can the company be responsible for any consequential loss. All labels should be retained until hanging is complete and to your satisfaction. If your wallpaper is an all-over dark colour, the ends of the rolls should be coloured with a matching crayon or marker to avoid white edges showing.

**To minimize the hazard in the event of fire, DO NOT hang wallpapers over expanded polystyrene veneers or any other flammable products, and ensure that wallcoverings are always firmly stuck down.**

### **Preparation:**

Walls should always be clean, firm and dry. Roughen any painted surfaces with glass/sandpaper. Remove any old wallcoverings, and fill any holes and cracks. Size any absorbent surfaces. Scrape powdery or flaky areas and paint with suitably prepared size, or oil-based primer, allowing it to dry completely.

### **Lining:**

It is important that the walls are cross-lined. Avoid white lining papers for dark wallpapers.

### **Adhesive:**

Ensure that a good quality Paste-the-wall "Tub" adhesive, containing a fungicide, is used with this wallcovering. Try to avoid getting adhesive on the printed surface. If it is unavoidable, gently wipe off with a clean dry sponge whilst it is moist, making sure to rinse it thoroughly throughout the cleaning process, using clear water only, and no soap or cleaning liquids of any kind.

### **Application:**

Cut your lengths allowing for Pattern Matching and for final trimming at the bottom. DO NOT assume that the wallpaper will come off the roll the right way up – this should always be checked. If unsure, consult the Timorous Beasties website or check with your retailer. Using a roller, apply plenty of paste to the wall, slightly wider than the drop you are about to hang, paying particular attention to the top and bottom. Dampen the non-woven backing and book for 2 minutes before hanging. Use a plumb line when hanging the first length and smooth the paper to the wall, using a paper hangers brush, from the centre of the length to the edge, to expel air bubbles. After hanging 3 or 4 lengths, inspect the result to ensure no shading or other faults are present. NO claim for redecorating costs can be allowed. Butt-join subsequent lengths. Good ventilation and an even temperature will assist in the even drying of wallpaper.

### **Wallpaper care:**

This wallpaper has a suede effect finish, which permits the removal of surface marks by gently brushing. Do not scrub or use any abrasive cleaning agents.

The information given in our specifications or technical / hanging advice, whether verbal or written is for guidance and is given in good faith but without warranty, as site conditions and levels of skill in application are beyond our control. We can accept no liability for the performance of the products arising out of such use, beyond the value of the goods supplied by us.