



TIMOROUS BEASTIES

Flocked Wallpaper Hanging Instructions

—

Minimum order: 1 x 10m roll
Roll size: approx 520mm by 10m
Material: Non woven ground with Flock made from Nylon (Polyamide 6.6 Flock fibre)
Fire Rating: Complies with Class B, s1, d0 when installed correctly

—

PLEASE READ CAREFULLY BEFORE HANGING THE PAPER.

IF YOU ARE IN ANY DOUBT REGARDING DIRECTION OF PATTERN PLEASE REFER TO WEBSITE AS WE ARE NOT RESPONSIBLE FOR INCORRECTLY HANGING PAPER AS THE ROLLS ARE SOMETIMES REVERSE ROLLED DUE TO MANUFACTURING PROCESS.

—

Inspect every roll to ensure that all rolls have the same batch number and are in good condition, with no variations in shade, and that no other faults are present. The company cannot accept liability for defects that are apparent at the time of hanging, nor can the company be responsible for any consequential loss.

Please retain all batch labels until decorating is completed. After hanging 2 or 3 lengths we strongly recommend that you carefully inspect the results.

—

Preparation:

- 1 Walls should be clean, firm, dry and smooth
- 2 Roughen painted surfaces with glass/sandpaper
- 3 Remove any old wallpaper.
- 4 Scrape powdery or flaky areas and paint with a suitably prepared size, allowing to dry completely
- 5 Ensure that the wall is an all-over light neutral colour with no highly contrasting areas.

Pasting:

- 1 Use a good quality, fungicide protected, wheat base ready-mixed paste.
- 2 Apply an even coat of paste to the wall.
- 3 Care should be taken not to crease the paper when folding.

Hanging:

- 1 Always check which way up the design is before hanging.
- 2 Butt the joins and use a clean soft roller to smooth down the wallcovering, working from centre to edges of paper to remove bubbles.
- 3 Avoid squeezing paste out of joins.
- 4 This product is not spongeable and can be damaged by paste or water on the surface.
- 5 No paste should be allowed to come into contact with the surface of the paper and hands should be kept clean and dry.
- 6 Dried paste could damage the surface of the wallcovering.
- 7 Ensure wallcovering is firmly stuck down, as, in the event of fire, loose coverings could contribute to the hazard. For the same reason it is recommended that this wallcovering should not be applied over expanded polystyrene wall veneers.

This information is supplied in good faith, but without guarantee and on the understanding that the installer will have the decorating knowledge to work with differing site or atmospheric conditions present at time of installation.

—

timorousbeasties.com