



Superwide Wallpaper Hanging Instructions

—

1350mm wide up to 50m rolls
Minimum order: 1m
Material: Non woven ground
Fire Rating : Complies with Class B, s1, d0 when installed correctly
280gsm per linear metre
Can be treated to ASTME84

—

PLEASE READ CAREFULLY BEFORE HANGING THE PAPER. IF YOU ARE IN ANY DOUBT REGARDING DIRECTION OF PATTERN PLEASE REFER TO WEBSITE AS WE ARE NOT RESPONSIBLE FOR INCORRECTLY HANGING PAPER AS THE ROLLS ARE SOMETIMES REVERSE ROLLED DUE TO MANUFACTURING PROCESS.

—

- 1 Prepare the walls in the normal way.
- 2 Check that all papers supplied are correct in good order and the correct quantity. We do not take responsibility once the paper is cut.
- 3 Use a good quality ready mixed tub paste.
- 4 Cross line the walls with at least 1000 grade lining paper.
- 5 Decide on the starting point in the room and plumb a line for the first drop or draw a faint vertical guide line. Be aware that marks on the lining paper may show through the pale background papers. It is advisable to test first.
- 6 Measure the length of the first drop adding sufficient excess top and bottom to allow for trimming. Take into account that variations in floor and ceiling level could occur.
- 7 Cut and number the drops required.
- 8 Paste the wall, ensuring generous and even coverage of the area to be covered by the first drop, paying particular attention to the edges, the top and bottom.
- 9 **nb:** Perforated edge is not to be taken as true, work from printed area only to ensure print is running straight. To hang the first drop, press it onto the pasted wall along the top. Keeping the rest of the paper off the wall align the edge of the paper to the vertical guide line. Once in position use a plastic spatula to smooth the paper downwards and outwards, removing all air bubbles. Trim top and bottom.
- 10 Paste the required area and hang the second drop overlapping the edge of the first drop by approx 20mm, to match the pattern. Secure the rest of the paper as before.
- 11 Cut through the centre of the overlap with a very sharp blade using a metal edge as a guide. Ensure metal cutting guide is appropriate for the wall surface. We recommend a short edge that is pliable enough to mould to the wall.
- 12 Pull away the two strips of paper, flap back the edges and re-paste. Press edges back into position to form a perfect join. Now trim top and bottom. **nb:** Wipe any paste off surface of wallcovering with a damp cloth. Ensure cutting bade is always sharp.

—

The information given in our specifications or technical/hanging advice, whether verbal or written is for guidance and is given in good faith but without warranty, as site conditions and levels of skill in application are beyond our control. We can accept no liability for the performance of the products arising out of such use, beyond the value of the goods supplied by us.

—

timorousbeasties.com